

Devices that are compatible with the mobile boosters:
(marked with a X)

Brand	Device	KBC-L2B	KBC-L3A
Apple	iPhone 3G, 3GS, 4, 4S	X	X
Apple	iPad 1 & 2	X	
Apple	iPod Touch	X	X
Apple	iPod Classic	X	X
Apple	iPod Nano	X	X
Apple	iPod Shuffle	X	X
Sony	Playstation Portable	X	X
Nintendo	DS	X	X
Nintendo	DS Lite	X	X
Nintendo	DSi	X	X
Nintendo	DSiLL	X	X
RIM	Blackberry Bold	X	X
RIM	Blackberry Curve	X	X
RIM	Blackberry Bold 9780	X	
Samsung	Galaxy S	X	X
Samsung	Armani Phone	X	X
Samsung	SGH-F480	X	X
LG	GD580	X	X
LG	Optimus bright	X	
Motorola	Backflip	X	X
Motorola	Milestone	X	X
Nokia	N97	X	X
HTC	Desire	X	X
HTC	Hero	X	
Sony Ericsson	X-10 (XPERIA)	X	X
Sony Ericsson	Xperia acro	X	
Sony Ericsson	Xperia play	X	
Sony Ericsson	Xperia neo	X	
Sony Ericsson	Xperia arc	X	